



Original Zubehör
Genuine Accessories
Accessoires d'Origine

Fitting Instructions

Electrical Installation Kit

Part number

4B0 055 200

Distributed by Votex GmbH
USA: Distributed by
Volkswagen of America Inc.
Auburn Hills / Mi.

Printed in West Germany
by Votex GmbH

Equipment supplied is subject to alteration

Electrical upgrade kit for check-control system

AUDI A2 02/00 >>
AUDI A3 09/96 >>
AUDI A4 11/94 >> 10/00
AUDI A6 05/97 >>

GB

Package includes:

- 1 Cable set, 3-core,
- 1 Socket housing, 1-way,
- 1 Socket housing, 2-way,
- 10 Cable ties 100 mm long.

Work to be carried out, in general:

1. Disconnect the ground cable from the battery.
2. Fit the 3-core cable set.
3. Functional check.

1. Disconnect the ground cable from the battery

In order to avoid short circuits during assembly and for safety reasons the ground cable has to be disconnected from the battery before starting the installation work (**fire hazard**) !!

Caution: On board computer / immobilizer!

**Stored data may be lost due to the battery being disconnected.
Comply with manufacturers' instructions**

2. Fit the 3-core cable set

Remove boot left side panelling and driver side footwell panelling.

Disconnect the existing 6-way plug connection of the **previously fitted** electrical installation kit for the trailer socket located behind the boot left side panelling.

The 6-way plug bridge is no longer required!

Also refer to: Installation instructions for electrical installation kit for 7-pin / 13-pin trailer coupling.

Connect and lock the 6-way plug connection of the enclosed 3-core cable set with the mating connector of the above mentioned cable set for the trailer socket.

Route the remaining cable end with the 1 and 2-way plug housings from the boot along left side of vehicle up to driver side footwell, and then up to installation location of **bulb check relay** (4B0 919 471, below fitting bracket, left of steering column)!

Disconnect **bulb check relay** from upper relay carrier and unclip the connection socket from rear of relay carrier.

Push open the secondary catch (**pink**) and push out the terminal sockets of the existing vehicle cables with a suitable removal tool.

AUDI A2 and AUDI A3:

grey/red (in chamber 10)
grey/black (in chamber 18)
red/black (in chamber 5)

(If necessary re-adjust the housing catches of the contacts after pushing out)

AUDI A4 and AUDI A6:

grey/white (in chamber 10)
grey/yellow (in chamber 18)
red/black (in chamber 5)

AUDI A2 and AUDI A3:

Connect and lock the terminal sockets of the removed vehicle cables **grey/red** and **grey/black** as follows in the enclosed **2-way plug housing**:

Cable grey/red in chamber 1
Cable grey/black in chamber 2

AUDI A4 and AUDI A6:

Connect and lock the terminal sockets of the removed vehicle cables **grey/white** and **grey/yellow** as follows in the enclosed **2-way plug housing**:

Cable grey/white in chamber 1
Cable grey/yellow in chamber 2

All models:

Connect and lock the terminal socket of the removed cable **red/black** in the enclosed **1-way plug housing**:

Connect and lock the assembled plug housing with the mating connector of the 3-core cable set.

Connect and lock the terminal sockets of the remaining cables **grey/red**, **grey/black** and **black/red** of the cable set in the free chambers of the connection socket for the :

Cable grey/red in chamber 10
Cable grey/black in chamber 18
Cable black/red in chamber 5

Re-lock the secondary catch, clip connection socket back into relay carrier and reconnect **bulb check relay** to relay carrier.

3. Functional check

Reconnect the ground cable to the battery.

Check all the functions of the trailer socket with a suitable tester.

Route all the cables of the installation kit alongside the existing cable wires, fix with the enclosed cable ties and/or place in the available cable retainers!

Refit all panelling and dismantled parts!