


- ◆ In footwell, front left
C - Fuse -1- (30) (power steering) (S204)

6+6-point relay carrier



- ◆ In footwell, front left
2 - Automatic intermittent wash/wipe relay (J31)
3 - Automatic intermittent wash/wipe relay (J31)